

Remote Volume Control Panel

Model RVCP

General

The RVCP fits in a standard single gang electrical box and may be installed using the included hardware. Be sure to make all electrical connections prior to installing the RVCP into an electrical box.

Electrical Connections

Minimum 24-gauge, 3 conductor wire is recommended. Maximum wire length run of 2,000 feet.

Connect similarly labeled terminals on the Bogen amplifier or control unit and RVCP together. UP to UP, Common (C) to Common (C), and down (DN) to down (DN).

DAISY-CHAINING

Multiple RVCP's can be daisy-chained from control panel to control panel for multiple locations. Parallel like labeled terminals on each RVCP together.

Orientation

Make certain that the RVCP is in the proper orientation when it is installed. The arrow on the back should be pointing up towards the ceiling.