

## DFT 120 TELEPHONE INPUT

The DFT120 has been engineered to operate from a LOOP START or a DRY LOOP (Page Port). If these are not available, a UTI1 (Universal Telephone Interface) will be needed.

