


# DFT120 to UTI312 PAGE PORT INPUT

The DFT120 is designed to accept a Loop Start or a Page Port .  
If these are not available the UTI1 will be required



On the UTI312 the Input Switches (not shown) must be set to "PAGE PORT" and "CONT ".

