


# Background Music


## PCM2000 HI PWR #1



In this configuration the background music will be muted only to the zone being paged.

# Background Music


## PCM2000 HI PWR #2



Line Level Background Music Source

In this configuration the background music will be muted to all zones when a page is made.  
 1 Amp BGM must be programmed to Enable.

# Background Music PCM2000 LO PWR #1



# Background Music

## PCM2000 LO PWR #2

Line Level Background Music Source

In this configuration the background music will be muted to all zones when a page is made.

1 Amp BGM must be programmed to Enable.

