



PBX to UTI1 switch set up

Loop Start- FXO



Station Port- FXS



Page Port w/ Closure

