

# CSD Speaker With Back Box Series Tap Settings

(Selector Switch shown at 1-Watt)

